



Roof Mount Stays kept away from dish stays to allow adjustment of dish